

Install 2-2" Conduits For Future

Use. Stub And Cap Conduit 2' past

The Edge Of The Foundation.

FOUNDATION PLAN

- 7 I" Sleeve (For Ground Rod) shall be inserted when foundation is poured.
- 8. For filtered ventilation hole pattern only; see T.S. 3-1, detail "E".
- 9. Ground rod shall be 5/8" dia. x 10'0" long.
- In unpayed areas a raised PCC pad 36 "x 4"x width of foundation, shall be placed in front of the cabinet. Pad shall be set 2" below the foundation elevation. Slope pad away from cabinet. See pad detail on T.S. 2-1.
- 11. Use grout or mastic to seal gap between cabinet and foundation.

